GSM MOBILE ALARM

Sensor alarm with alerts straight to your phone www.gsmactivate.co.uk



Product Information

Our GSM Mobile Alarm is a standalone small portable unit which can be deployed in your Rooms, Workshops, Sheds, Boats, Caravans, and endless other places where you need to safeguard the security of you, your family and belongings.

Our units are made in the UK but, with quadband GSM frequency the units can be used all over the world, there is no installation or programming required, you simply place a 2g simcard into the unit plug it in (power supply and antenna are included) and it is ready to be used. The alarm has a built in program which monitors the simcard and keeps it alive so you never have to worry about the simcard and unit being deactivated.

The unit has an internal PIR sensor which works most effectively over 5 Metres/16 Feet. When the sensor is triggered it will use the internal GSM technology to send you a text message or phone call straight to your mobile phone or landline so you know straight away if there is a problem you should be aware about! Once you have received an alert message or call you can then dial into your unit and access the unit's microphone to listen in to what is happening and then reactivate the unit or leave it in standby mode.

- GSM Frequency: Quad band freq 850/900/1800/1900 MHz
- Power Supply Voltage: 12 vdc 1Amp max
- Current used in standby mode: 25mA max
- Standard 2G simcard
- No Landline Required
- □ Dimensions L125 xW80 xH40mm
- Operating Temperature: -10...+40°C
- Text for signal strength
- Sensor Range 5 Metres/16 Feet
- Call or Text Alerts
- Sensitivity Adjustment
- Dial-in to built in microphone allows you to listen into surroundings.
- 3 Metre Antenna included
- 12vdc Power Supply included
- Stay Active Sim Function

INSTRUCTION



Motion detector

Dipswitch 1 On = High Sensitivity Dipswitch 1 Off = Low Sensitivity

Dipswitch 2 On = Text message Dipswitch 2 Off = Phone call

- 1: Slide back the sim door and lift it up.
- 2: Slide the simcard in to the door making sure that the clipped corner of the simcard lines up with the top left hand corner of the sim holder.
- 3: Close the sim door.
- 4: Slide the sim door to lock the sim in place

Please make sure you disconnect the power when you fit the simcard

You must disable any voicemail that is set on the simcard using the codes -

Vodaphone: call 1210
Orange: call 450
Tesco call 2915
T-Mobile: call 222
02: call 1760
Giff Gaff: call 1626

NOTES

Please note as PIR Sensors react to heat be sure to place the unit away from radiatiors / boilers and similar heat sources, the units can also be triggered by direct sunlight so also be sure to place them in a suitable place.

How to setup your Mobile alarm

- 1: First you will need to remove the four fixing screws holding the back cover plate.
- 2: Place the simcard into the simcard Holder, please look at the picture above and follow the instructions. Note please make sure that you have turned off voice mail on your simcard ref to page 3
- 3: Now we need to set the Dipswitch 1 & 2. Dipswitch 1. This is for the Alarm sensitivity if you turn the switch on this will increase the sensitivity, this may detect small animals so we recommend that you leave Dipswitch one in the off position.

Dipswitch 2. You can select to receive a text call or phone call when the alarm has been activated.

If you turn Dipswitch 2 ON you will receive a text message saying alarm activated.

If you turn Dipswitch 2 OFF you will receive a phone call, you do not need to answer this call as it will automatically hang up after it has made six ring tones, this will prevent any call charges being made to your simcard.

- 4: Refit the back cover using the four corner screws.
- 5: Place the alarm in a suitable place. It is important to place the mobile alarm away from direct sunlight or close to radiator as this may cause false alarms.
- 6: Connect the power supply to the power input socket.
- 7: Connect the antenna to the screw terminal placing the antenna as high as possible.

How to program the Mobile Alarm

- 1: Turn on the power to the mobile alarm you will see the red standby light come on, after a short period of time approximately 20 to 50 seconds the red light will start to flash and you will hear two beep sounds this tells you that the unit has found a mobile signal and is ready for programming.
- 2: The mobile alarm now needs to be programmed with up to two numbers, these numbers will be used to contact you if your alarm is activated. We do this by sending a text to the simcard number follow the example below.

```
(Hash) (Star) (number) (star)
# 1* 01798865555* Now send to the simcard number
# 2* 07748435555* Now send to the simcard number
You can only text one at a time
```

If you wish to cancel a number send a text as follows. # 1** or if is for number 2 then # 2**

You are now ready to activate the alarm.

You can activate the unit two ways

- 1) Press the set/clear button, once pressed the blue alarm on light start to flash for 45 seconds, this is to give you time to leave the area before the alarm becomes set.
- 2) You can also activate by sending a text message # ON this has the same effect as pressing the set/clear button.

After 45 seconds you will hear the unit beep and that is confirmation it is now alarmed. Any movements in the room from now on will trigger the alarm and send out text/phone alerts.

Walk Test (green light)

The green walk test light will illuminate when the sensor detects movement, so you can test the sensitivity before you set the alarm.

What to do when alarm is activated (reset)

When the alarm has been triggered it will send you a call or text and then return to standby mode. To reset the alarm use the same method as activating the alarm either by the set/clear button or by texting # ON

<u>Microphone</u>

To listen in to the surrounding area of the mobile alarm you can dial in by calling the units simcard number, this will go straight through to the microphone and you will hear any activity that is occurring, this is useful to identify false alarms.

Switch Off

To switch off the alarm press the set/clear button when it is in alarm mode or send a text # OFF.

Signal Strength

To help make sure that you place the unit in a suitable position You can text the unit to see how much signal strength you have by texting #SS, this will indicate the signal strength, you will receive a text telling you if it's GOOD, AVERAGE, POOR. We strongly recommend that you place the unit where you can get at least average signal strength You will find that with a poor signal it will be unreliable and is not suitable.

<u>Text Acknowledgements</u>

You get text acknowledgements every time the alarm is switched on or off, these will say Alarm On or Alarm Off.

It may take a time to send or receive a text acknowledgement this depends upon how busy your telephone network is at the time.

Typical application:

- Workshops
- Offices
- Bedrooms
- Sheds
- Caravans / Mobile Homes
- Boats
- Hotel Rooms

Quick reference

Send Text	Operation	Acknowledgment
# ON	Turn Alarm on	Alarm on
# OFF	Turn Alarm off	Alarm off
# SS	Check signal strength	Good, Ave, Poor
# 1* 12345679989*	To store phone number	1 stored
# 2* 12345676767*	To store phone number	2 stored

For more technical information please contact us,

Phone 01798 861346

Email gsmswitch@hotmail.co.uk